Prepare a heatmap of the positively age correlated genes for publication.

Jason Kennerdell 8/12/2018

Input the data and metadata:

```
inpath <- "~/Desktop/brain"</pre>
outpath <- "~/Desktop/brain/_8A_ageCorGenes_htmp"</pre>
colSet <- brewer.pal(12, "Paired")</pre>
files <- list.files(inpath)</pre>
htseq_files <- files[grep1("^JKL.*txt$", files)]</pre>
sampleNames <- read.csv(file.path(inpath, "SampleNames.csv"))</pre>
sampleTable <- data.frame(fileName = htseq_files,</pre>
                            stringsAsFactors=FALSE)
sampleTable$Library <- gsub("-counts.txt", "", sampleTable$fileName)</pre>
sampleTable$Library <- gsub("b", "", sampleTable$Library)</pre>
sampleTable$seq.batch <- ifelse(grep1("b", sampleTable$fileName), "B", "A")</pre>
sampleTable$seq.batch <- paste(sampleTable$Library, sampleTable$seq.batch)</pre>
sampleTable <- merge(sampleTable, sampleNames[,1:3], by = "seq.batch")</pre>
sampleTable$genotype <- gsub("-.*$", "", sampleTable$Sample)</pre>
sampleTable$genotype <- gsub("JKLY.... ", "", sampleTable$genotype)</pre>
sampleTable$genotype <- gsub("\\[1118\\]", "", sampleTable$genotype)</pre>
sampleTable$genotype <- factor(sampleTable$genotype, levels = c("w", "Ez"))</pre>
sampleTable <- sampleTable[!is.na(sampleTable$genotype),]</pre>
sampleTable$Temp <- gsub("[A-Z, a-z, -]", "", sampleTable$Sample)</pre>
sampleTable$Temp <- gsub("^11.*$", "25", sampleTable$Temp)</pre>
sampleTable$Temp <- factor(sampleTable$Temp, levels = c("25", "29"))</pre>
sampleTable$age <- gsub("JKLY.*$", "3d", sampleTable$Sample)</pre>
sampleTable$age <- gsub("^[a-zA-z].*$", "20d", sampleTable$age)</pre>
sampleTable$age <- factor(sampleTable$age, levels = c("3d", "20d"))</pre>
sampleTable$condition <- paste(sampleTable$genotype, sampleTable$Temp,</pre>
                                  sampleTable$age, sep = "-")
sampleTable$color <- c(rep(colSet[7], 4), rep(colSet[9], 2),</pre>
                         rep(colSet[8], 2), rep(colSet[10], 2),
                         rep(colSet[8], 2), rep(colSet[10], 2),
                         rep(colSet[8], 2), rep(colSet[10], 2),
                         rep(colSet[8], 2), rep(colSet[1], 2),
                         rep(colSet[10], 2), rep(colSet[8], 2),
                         rep(colSet[10], 2), rep(colSet[1], 4),
                         rep(colSet[7], 2), rep(colSet[9], 4))
sampleTable
```

```
##
     seq.batch
                        fileName Library
                                                   Sample batch genotype
## 3
       JKL10 A JKL10-counts.txt
                                   JKL10
                                                  w-25-II
                                                             Α
## 4
       JKL10 B JKL10b-counts.txt
                                   JKL10
                                                  w-25-II
## 5
       JKL11 A JKL11-counts.txt
                                   JKL11
                                                 w-25-III
                                                             Α
                                                                       W
## 6
       JKL11 B JKL11b-counts.txt
                                   JKL11
                                                 w-25-III
```

```
## 7
        JKL12 A JKL12-counts.txt
                                      JKL12
                                                    Ez-25-III
                                                                   Α
                                                                           Ez
## 8
        JKL12 B JKL12b-counts.txt
                                      JKI.12
                                                    Ez-25-III
                                                                           Ez
                                                                   В
## 9
        JKL13 A JKL13-counts.txt
                                      JKL13
                                                       w-29-I
                                                                   Α
                                                                            W
## 10
        JKL13 B JKL13b-counts.txt
                                      JKL13
                                                       w-29-I
                                                                   В
                                                                            W
## 11
        JKL14 A JKL14-counts.txt
                                      JKL14
                                                      Ez-29-I
                                                                   Α
                                                                           F.z.
        JKL14 B JKL14b-counts.txt
## 12
                                                      Ez-29-I
                                      JKL14
                                                                   R
                                                                           F.z.
## 13
        JKL15 A JKL15-counts.txt
                                      JKL15
                                                      w-29-II
                                                                   Α
                                                                            W
        JKL15 B JKL15b-counts.txt
## 14
                                      JKL15
                                                      w-29-II
                                                                   В
                                                                            W
## 15
        JKL16 A JKL16-counts.txt
                                      JKL16
                                                     Ez-29-II
                                                                   Α
                                                                           Ez
## 16
        JKL16 B JKL16b-counts.txt
                                      JKL16
                                                     Ez-29-II
                                                                   R
                                                                           Ez
## 17
        JKL17 A JKL17-counts.txt
                                      JKL17
                                                     w-29-III
                                                                   Α
                                                                            W
## 18
        JKL17 B JKL17b-counts.txt
                                                     w-29-III
                                      JKL17
                                                                   В
                                                                            W
## 19
        JKL18 A JKL18-counts.txt
                                      JKL18
                                                    Ez-29-III
                                                                   Α
                                                                           Ez
## 20
        JKL18 B JKL18b-counts.txt
                                      JKL18
                                                    Ez-29-III
                                                                   В
                                                                           Ez
## 21
        JKL19 A JKL19-counts.txt
                                      JKL19
                                                      w-29-IV
                                                                   Α
                                                                            W
## 22
        JKL19 B JKL19b-counts.txt
                                      JKL19
                                                      w-29-IV
                                                                   В
                                                                            W
## 23
         JKL2 A
                   JKL2-counts.txt
                                       JKL2 JKLY1125 w[1118]
                                                                   Α
                                                                            W
## 24
         JKL2 B
                 JKL2b-counts.txt
                                       JKL2 JKLY1125 w[1118]
                                                                            W
## 25
        JKL20 A JKL20-counts.txt
                                      JKL20
                                                     Ez-29-IV
                                                                   Α
                                                                           F.z.
## 26
        JKL20 B JKL20b-counts.txt
                                      JKL20
                                                     Ez-29-IV
                                                                   В
                                                                           F.z.
        JKL21 A JKL21-counts.txt
## 27
                                      JKL21
                                                       w-29-V
                                                                   Α
                                                                            W
## 28
        JKL21 B JKL21b-counts.txt
                                      JKL21
                                                       w-29-V
                                                                   В
                                                                            W
## 29
        JKL22 A JKL22-counts.txt
                                      JKL22
                                                      Ez-29-V
                                                                           F.z.
                                                                   Α
## 30
        JKL22 B JKL22b-counts.txt
                                                      Ez-29-V
                                      JKL22
                                                                   В
                                                                           F.z.
                                       JKL4 JKLY1127 w[1118]
## 33
         JKL4 A
                   JKL4-counts.txt
                                                                   Α
                                                                            W
## 34
         JKL4 B
                 JKL4b-counts.txt
                                       JKL4 JKLY1127 w[1118]
                                                                   В
                                                                            W
## 37
         JKL6 A
                   JKL6-counts.txt
                                       JKL6 JKLY1129 w[1118]
                                                                   Α
                                                                            W
## 38
         JKL6 B
                  JKL6b-counts.txt
                                       JKL6 JKLY1129 w[1118]
                                                                   В
                                                                            W
## 39
         JKL7 A
                                       JKL7
                                                       w-25-I
                   JKL7-counts.txt
                                                                   Α
                                                                            W
## 40
         JKL7 B
                  JKL7b-counts.txt
                                       JKL7
                                                       w-25-I
                                                                   В
                                                                            W
## 41
         JKL8 A
                   JKL8-counts.txt
                                       JKL8
                                                      Ez-25-I
                                                                   Α
                                                                           Ez
## 42
         JKL8 B
                  JKL8b-counts.txt
                                       JKL8
                                                      Ez-25-I
                                                                   В
                                                                           Ez
## 43
         JKL9 A
                   JKL9-counts.txt
                                       JKL9
                                                     Ez-25-II
                                                                           Ez
                                                                   Α
## 44
         JKL9 B JKL9b-counts.txt
                                       JKL9
                                                     Ez-25-II
                                                                   В
                                                                           Ez
##
      Temp age condition
                            color
## 3
        25 20d w-25-20d #FDBF6F
## 4
        25 20d w-25-20d #FDBF6F
## 5
        25 20d w-25-20d #FDBF6F
## 6
        25 20d w-25-20d #FDBF6F
## 7
        25 20d Ez-25-20d #CAB2D6
## 8
        25 20d Ez-25-20d #CAB2D6
## 9
        29 20d w-29-20d #FF7F00
        29 20d w-29-20d #FF7F00
## 10
## 11
        29 20d Ez-29-20d #6A3D9A
        29 20d Ez-29-20d #6A3D9A
## 12
        29 20d w-29-20d #FF7F00
## 13
        29 20d w-29-20d #FF7F00
##
  14
        29 20d Ez-29-20d #6A3D9A
## 15
## 16
        29 20d Ez-29-20d #6A3D9A
## 17
        29 20d w-29-20d #FF7F00
## 18
        29 20d w-29-20d #FF7F00
## 19
        29 20d Ez-29-20d #6A3D9A
## 20
        29 20d Ez-29-20d #6A3D9A
## 21
        29 20d w-29-20d #FF7F00
```

```
## 22
       29 20d w-29-20d #FF7F00
## 23
       25 3d
                w-25-3d #A6CEE3
## 24
       25 3d
                 w-25-3d #A6CEE3
## 25
       29 20d Ez-29-20d #6A3D9A
## 26
       29 20d Ez-29-20d #6A3D9A
## 27
       29 20d w-29-20d #FF7F00
## 28
       29 20d w-29-20d #FF7F00
       29 20d Ez-29-20d #6A3D9A
## 29
## 30
       29 20d Ez-29-20d #6A3D9A
## 33
       25 3d
                w-25-3d #A6CEE3
## 34
       25 3d
                w-25-3d #A6CEE3
## 37
       25 3d
                w-25-3d #A6CEE3
## 38
       25 3d
                w-25-3d #A6CEE3
## 39
       25 20d w-25-20d #FDBF6F
## 40
       25 20d w-25-20d #FDBF6F
## 41
       25 20d Ez-25-20d #CAB2D6
## 42
       25 20d Ez-25-20d #CAB2D6
## 43
       25 20d Ez-25-20d #CAB2D6
## 44
       25 20d Ez-25-20d #CAB2D6
```

Set up the statistical model to test for Differentially Expressed genes in E(z) mutants:

```
design <- formula(~ Temp + age + genotype)</pre>
```

DESeq2 Statistics

Import Age-Correlated Genes and look for how these genes change in E(z) mutants:

```
#listDatasets(mart)
mart = useMart("ENSEMBL_MART_ENSEMBL", host="aug2017.archive.ensembl.org",
               dataset = "dmelanogaster_gene_ensembl")
#listAttributes(mart)
genemap2 <- getBM(attributes = c("affy_drosophila_2", "ensembl_gene_id",</pre>
                                 "entrezgene",
                                 "flybasecgid_gene"),
                  filters = "affy drosophila 2",
                  values = as.character(ageCorGenes$Probeset.ID),
                  mart = mart)
idx2 <- match(ageCorGenes$Probeset.ID, genemap2$affy_drosophila_2)</pre>
ageCorGenes$ensembl <- genemap2$ensembl_gene_id[idx2]</pre>
ageCorGenes$geneSymbol <- genemap2$external_gene_name[idx2]</pre>
ageCorGenes$cg <- genemap2$flybasecgid_gene[idx2]</pre>
# Four probesets have NA ensembl names
# Fix a problem getting the FBqn names
ageCorGenes[is.na(ageCorGenes$ensembl),]
        Probeset.ID Fly.gene.ID Fly.gene.
                                           Beta1 p.value FDR..q.value.
                                     <NA> 58.816 4.48e-05
## 50 1632683 s at
                           <NA>
                                                                   0.0159
## 64
         1631089 at
                           <NA>
                                     <NA> 31.825 2.18e-04
                                                                   0.0324
## 120 1624543 s at
                           <NA>
                                     <NA> 36.057 8.12e-05
                                                                   0.0203
                        CG10494
                                     <NA> -73.867 4.75e-04
## 140 1638075_a_at
                                                                   0.0472
       control.log2.20d.3d.. mir.34.....log2.20d.3d. DIR2
##
                                                                   dd3
## 50
                   0.2535215
                                           0.5540302
                                                        1 0.30050871
## 64
                   0.7630460
                                           0.9473263
                                                      1 0.18428027
## 120
                   0.5560126
                                           0.5036011 1 -0.05241152
## 140
                  -0.7401696
                                          -0.5919468 -1 0.14822273
##
           dd.dir4 ensembl
## 50
        0.30050871
                      <NA> <NA>
        0.18428027
                      <NA> <NA>
## 64
## 120 -0.05241152
                      <NA> <NA>
## 140 -0.14822273
                      <NA> <NA>
# of CG10494:
ageCorGenes[140, 12] <- "FBgn0034634"
# CG5953 Or copia/GIP
ageCorGenes[50, 12] <- "FBgn0032587" # OR FBqn0013437
# Two others that are not associated with FBgn
ageCorGenesPos <- ageCorGenes[ageCorGenes$DIR2==1,]</pre>
ageCorGenesNeg <- ageCorGenes[ageCorGenes$DIR2==-1,]</pre>
ageCorGenesPos[is.na(ageCorGenesPos$ensembl),]
        Probeset.ID Fly.gene.ID Fly.gene. Beta1 p.value FDR..q.value.
##
## 64
         1631089_at
                           <NA>
                                     <NA> 31.825 2.18e-04
                                                                  0.0324
                                     <NA> 36.057 8.12e-05
                                                                  0.0203
## 120 1624543 s at
                           <NA>
       control.log2.20d.3d.. mir.34.....log2.20d.3d. DIR2
##
                                                                   dd3
## 64
                   0.7630460
                                           0.9473263
                                                        1 0.18428027
## 120
                   0.5560126
                                           0.5036011
                                                         1 -0.05241152
##
           dd.dir4 ensembl
                             cg
        0.18428027
                      <NA> <NA>
## 120 -0.05241152
                      <NA> <NA>
```


```
ageCorGenesNeg[is.na(ageCorGenesNeg$ensembl),]
    [1] Probeset.ID
                                 Fly.gene.ID
##
    [3] Fly.gene.
                                 Beta1
    [5] p.value
                                 FDR..q.value.
    [7] control.log2.20d.3d..
                                 mir.34....log2.20d.3d.
   [9] DIR2
## [11] dd.dir4
                                 ensembl
## [13] cg
## <0 rows> (or 0-length row.names)
Prepare rlog transformed data:
rld <- rlog(dds, blind=FALSE)</pre>
Get E(z) data statistics data without the influence of 3d data in the model:
design2 <- formula(~ Temp + genotype)</pre>
dds2 <- DESeqDataSetFromHTSeqCount(sampleTable = sampleTable[sampleTable$age != "3d",],</pre>
                                   directory = inpath, design = design2)
# Combine the technical replicates (different runs) by adding the count
# totals for each gene across the two runs:
dds2 <- collapseReplicates(dds2, groupby=dds2$Library, run = dds2$batch)
dds2 <- DESeq(dds2)
## estimating size factors
## estimating dispersions
## gene-wise dispersion estimates
## mean-dispersion relationship
## final dispersion estimates
## fitting model and testing
# What does the data look like?
head(assay(dds2))
               JKL10 JKL11 JKL12 JKL13 JKL14 JKL15 JKL16 JKL17 JKL18 JKL19
##
## FBgn0000003
                          0
                                0
                                      0
                                                               0
                                            0
                                                   0
## FBgn0000008
                1444
                      1874
                             1687
                                   1305
                                         1453
                                                1725
                                                      1529
                                                            1856
                                                                  1500
                                                                         1558
## FBgn000014
                          0
                                0
                   0
                                      0
                                            0
                                                   0
                                                         1
                                                               0
                                                                      1
                                                                            0
## FBgn000015
                   1
                          6
                                1
                                      3
                                            0
                                                   1
                                                         1
                                                               1
## FBgn000017
                                         8808
                9186 10798
                             9189
                                   6877
                                                9121
                                                      9834 11313
                                                                  9272
                                                                         8564
## FBgn0000018
                 262
                        306
                              286
                                    336
                                          288
                                                 317
                                                                          285
                                                             346
               JKL20 JKL21 JKL22
                                   JKL7
##
                                          JKL8
                                                JKL9
## FBgn0000003
                   1
                          0
                                0
                                      0
                                            0
## FBgn0000008
               1353
                      1589
                             1367
                                   1980
                                          1861
                                                1884
## FBgn000014
                   1
                          1
                                1
                                      0
                                             3
                                                   0
                          1
                                0
                                      0
                                             0
## FBgn0000015
                   0
## FBgn0000017 8697
                      8196
                            8612 11453 11360 11139
## FBgn0000018
                 285
                        238
                              284
                                    286
                                          333
```

```
# What are the columns?
colData(dds2)
## DataFrame with 16 rows and 10 columns
##
             Library
                        Sample
                                  batch genotype
                                                     Temp
                                                                age
##
         <character> <factor> <factor> <factor> <factor> <factor>
## JKL10
               JKL10
                     w-25-II
                                                        25
                                      Α
                                                                20d
                                               W
## JKL11
               JKL11 w-25-III
                                      Α
                                               W
                                                        25
                                                                20d
               JKL12 Ez-25-III
                                                        25
                                                                20d
## JKL12
                                      Α
                                              Ez
## JKL13
               JKL13
                      w-29-I
                                                        29
                                                                20d
                                      Α
                                               W
## JKL14
               JKL14
                     Ez-29-I
                                                        29
                                                                20d
                                      Α
                                              Ez
## ...
                . . .
                           . . .
                                     . . .
                                              . . .
                                                       . . .
                                                                . . .
## JKL21
               JKL21
                                                                20d
                        w-29-V
                                      Α
                                              W
                                                        29
## JKL22
               JKL22
                      Ez-29-V
                                      Α
                                              Ez
                                                        29
                                                                20d
## JKL7
                JKL7
                       w-25-I
                                                        25
                                                                20d
                                      Α
                                               W
## JKL8
                JKL8
                                                                20d
                      Ez-25-I
                                      Α
                                              Ez
                                                        25
## JKL9
                JKL9 Ez-25-II
                                      Α
                                              Ez
                                                        25
                                                                20d
##
                           color runsCollapsed sizeFactor
           condition
##
         <character> <character>
                                  <character> <numeric>
## JKL10
           w-25-20d
                         #FDBF6F
                                           A,B 0.9090574
## JKL11
                         #FDBF6F
                                           A,B 1.1403424
           w-25-20d
## JKL12 Ez-25-20d
                         #CAB2D6
                                           A,B 1.0027251
## JKL13
           w-29-20d
                         #FF7F00
                                           A,B
                                                1.0220507
## JKL14
           Ez-29-20d
                         #6A3D9A
                                           A,B 0.9570594
                . . .
                         . . .
                                           . . .
## JKL21
           w-29-20d
                         #FF7F00
                                           A,B 0.8750556
## JKL22
         Ez-29-20d
                       #6A3D9A
                                           A,B 0.9618390
## JKL7
                         #FDBF6F
           w-25-20d
                                           A,B 1.1341278
## JKL8
           Ez-25-20d
                         #CAB2D6
                                           A,B 1.1093046
          Ez-25-20d
## JKL9
                         #CAB2D6
                                           A,B 1.1303920
datEz <- results(dds2, alpha=0.05)
datEz$ensembl <- rownames(datEz)</pre>
```

Heatmap for age-correlated genes only:

```
# Make a function to assign genes to categories, shaded by log2FoldChange:
calledEz <- subset(datEz, padj < 0.05 & abs(log2FoldChange) > 0.5)
relaxedEz <- subset(datEz, padj < 0.05 & abs(log2FoldChange) > 0.3)
relaxedrelaxedEz <- subset(datEz, padj < 0.05 & abs(log2FoldChange) > 0.15)
Ezassign <- function(x){</pre>
  y <- rep(NA, length(x))
  for(i in 1:length(x))
    if(x[i] %in% calledEz[calledEz$log2FoldChange<0,7])</pre>
      #y[i] <- colSet[2]
      y[i] <- "#1F78B4"
    else if(x[i] %in% relaxedEz[relaxedEz$log2FoldChange<0,7])</pre>
      #y[i] \leftarrow colSet[12]
      y[i] <- "#84B5A8"
    else if(x[i] %in% relaxedrelaxedEz[relaxedrelaxedEz$log2FoldChange<0,7])</pre>
      #y[i] \leftarrow colSet[11]
      y[i] <- "#DDEB9D"
    else
```

```
y[i] <- NA
У
}
ageCorPosIndex <- which(rownames(rld) %in% ageCorGenesPos$ensembl)</pre>
# Remove one gene that is not expressed in brains (Hsp22)
ageCorPosIndex <- ageCorPosIndex[-2]</pre>
dat <- scale(t(assay(rld)[ageCorPosIndex,]))</pre>
attr(dat, "color") <- colData(dds)$color</pre>
attr(dat, "condition") <- colData(dds)$condition</pre>
gene <- attr(dat, which = "dimnames")[[2]]</pre>
myColors <- Ezassign(gene)</pre>
table(myColors)
## myColors
## #1F78B4 #84B5A8 #DDEB9D
        16
                14
                         13
# Print out a figure
par(cex.main=1)
htmp <- heatmap.2(dat,</pre>
          lmat=rbind(c(6,5,0), c(0,2,0), c(4,3,1)),
          lwid=c(1, 4, .1),
          lhei=c(1.5, 0.2, 4),
          cexRow=1.2, cexCol=0.75, scale="none", offsetRow=-1, srtRow=45,
          col=colorpanel(75, "green", "black", "magenta"),
          trace="none",
          RowSideColors = attr(dat, which = "color"),
          ColSideColors = myColors,
          margins=c(5,0.5),
          key.par=list(cex.main=1),
          key=T, main="Positively Age-Correlated Genes",
          key.xlab = "column z-score",
          labRow=NA
```



```
jpeg(file=paste(outpath, "Fig_8a_AgeCorPosGreenMag.jpg", sep="/"),
     quality=100,
     res=300,
     height=1920,
     width=3840)
par(cex.main=1, bg="transparent")
heatmap.2(dat,
          lmat=rbind(c(6,5,0), c(0,2,0), c(4,3,1)),
          lwid=c(1, 6, .1),
          lhei=c(1.5, 0.3, 4),
          cexRow=1.2, cexCol=0.9, scale="none",
          offsetRow=-1,
          offsetCol = -0.5,
          srtRow=45,
          col=colorpanel(75, "green", "black", "magenta"),
          trace="none",
          RowSideColors = attr(dat, which = "color"),
          ColSideColors = myColors,
          margins=c(5,0.5),
          key.par=list(cex.main=1),
          key=T, main="", key.title="",
          key.xlab = "", key.ylab="",
          labRow=NA
dev.off()
```

pdf

2

Which are these 16 genes?

```
hits <- intersect(calledEz[calledEz$log2FoldChange<0,7],ageCorGenesPos$ensembl)
calledEz[calledEz$ensembl %in% hits,]
## log2 fold change (MAP): genotype Ez vs w
## Wald test p-value: genotype Ez vs w
## DataFrame with 16 rows and 7 columns
##
                baseMean log2FoldChange
                                             lfcSE
                                                         stat
                                                                    pvalue
               <numeric>
                              <numeric>
                                         <numeric>
                                                    <numeric>
                                                                 <numeric>
## FBgn0030159
               903.40013
                             -0.8058498
                                         0.1068034
                                                    -7.545168 4.517053e-14
                                         0.1526684 -7.216768 5.323750e-13
## FBgn0030310
                62.52550
                             -1.1017723
## FBgn0030482
               578.84903
                             ## FBgn0032810
                58.59347
                             -0.6669497   0.1374054   -4.853882   1.210677e-06
## FBgn0033574
                48.60368
                             -1.0880644 0.1511080 -7.200573 5.995998e-13
## ...
                     . . .
                                    . . .
                                               . . .
                                                          . . .
## FBgn0038465 6612.20978
                             -1.4478882 0.08271313 -17.504938 1.313689e-68
## FBgn0043578
                             -0.7415507 0.14974260 -4.952170 7.339060e-07
               170.52543
## FBgn0052368 676.41495
                             -1.3299033 0.15802778 -8.415630 3.907882e-17
## FBgn0052640
                10.96169
                             -1.4864518 0.15807399 -9.403520 5.276775e-21
## FBgn0261560
               344.98792
                             -0.7884363 0.13302505 -5.926977 3.085627e-09
##
                               ensembl
                      padj
                  <numeric> <character>
##
## FBgn0030159 1.781031e-12 FBgn0030159
## FBgn0030310 1.927359e-11 FBgn0030310
## FBgn0030482 1.553753e-12 FBgn0030482
## FBgn0032810 1.962545e-05 FBgn0032810
## FBgn0033574 2.151177e-11 FBgn0033574
## FBgn0038465 3.138928e-66 FBgn0038465
## FBgn0043578 1.233189e-05 FBgn0043578
## FBgn0052368 1.992009e-15 FBgn0052368
## FBgn0052640 3.444898e-19 FBgn0052640
## FBgn0261560 7.492681e-08 FBgn0261560
```